



**Swivel seat DRIVER  
CBTO19G2C**

**+ ACAFMTC**

- Remove the handbrake cover
- Remove battery from case
- Remove handbrake without disconnecting break cables

**Swivel seat PASSENGER  
CBTO19D2C:**

If seats are non-height adjustable you may need to cut the side seat panels to access seat sliders (see below)

(If needed) Cut side panels 10mm to align with seat sliders

- 3x nylon locking nuts M8
- 3x Hexagon Socket Head Screw M8x20

- ACAFMTC
- 3x Hexagon Head Cap Screws M8x20

- 3x nylon locking nuts M8

Handbrake

Remove the 2 welded screws

Remove pins



Ford Transit original seat

4x nylon locking nuts M8

4x washers M8x18x1.5

4x Hexagon Head Cap Screw M8x20

SWIVEL SEAT

4x Hexagon Socket Head Screw M8x20

Ford Transit original base

**travois**  
adventure is calling